



FUNCTIONAL SPECIFICATIONS

Compensation valve positioned at the end of the zone closing the ring, used for filling the liquid during installation and for pressure compensation when a weight is placed on a single tube.

Used also for periodic checking of the system pressure.

Dimensions: 90x90x100(h) mm

01-09-2017